



This document provides a step-by-step installation procedure for the ETAP Software, including libraries, example projects, and help files.

## Installation Options

Download the ETAP Student Edition from the email sent by the ETAP university team. This email also includes the installation code which is required when installing the Student Edition.

## Before Installing ETAP

1. You must have administrator rights to your computer
2. Close all other applications.  
Note: ETAP installation will automatically include engineering device library (.lib) and main program executable (etaps64.exe) into Windows Defender Exclusion List. This is to prevent Windows Defender from scanning the engineering library when linked to a project file.

## Activation Code

As needed, ETAP will prompt you for a software Activation Code, which will be sent via email once you have activated the student edition.


## Software Prerequisites

ETAP automatically installs prerequisites as needed. For a complete list of prerequisites, refer to the System Requirements section of this installation guide.


### 1. ETAP Installation Manager



### 2. License Agreement




### 3. Welcome



### 4. Installation Code




### 5. System Requirements



## 6. Previous Version Reports



## 7. Installation Path Selection




## 8. Installation Complete




## 9. Restart Computer

## Activating the Student Edition (Internet is required)


1. Launch ETAP



2. Enter the email address used to sign up for the Student Edition



3. The activation code will automatically be sent to your email



4. Copy and paste the activation code

